

Due to the increased size of the file, the internal memory structure has changed. This means any units running V1 boot code will need to update to a transition code (V1.5+), then update to V2 through that. Also any future updates will need to be done through the main firmware using the web server GUI.