

RM-X-64 Firmware Update Notes

Main Unit Firmware (.swu)

The .swu file updates the firmware in both the main microprocessor and the FPGA.

This file must be uploaded via the web user interface served directly by the unit.

Refer to the RM-X-64 user manual for detailed instructions on accessing the web interface.

Reset (“Defaults”) Firmware

The Reset Firmware folder contains a special “defaults” version of the .swu firmware.

Installing this version:

- Clears the current configuration
- Resets user settings on the main unit
- Resets the unit to its factory-default settings

This firmware should only be used if a corrupted or invalid configuration prevents normal operation, or if a standard firmware update does not resolve the issue.